Bomac Marine Power Corp. Lehman Ford Routine Maintenance Guide

217 Commerce Drive, Blairsville, GA 30512

Ph 954-766-2625 866-419-6363 Fax 706-835-1923

ENGINE OIL AND FILTER	CHANGE EVERY 150 HOURS
WATER PUMP IMPELLER	CHECK EVERY 200 HOURS IF IMPELLER IS DAMAGED- REPLACE.IMMEDIATELY AND LOOK FOR BROKEN PIECES IN FRONT OF OIL COOLER AND REMOVE PIECES)
PRIMARY & SECONDARY FUEL F	TILTERS CHANGE EVERY 300 HRS. OR EVERY 6 MONTHS.
TRANSMISSION	.CHANGE FLUID YEARLY, REPLACE TRANSMISSION OIL COOLERS EVERY 2 TO 3 YEARS.
HEAT EXCHANGER	.CLEAN YEARLY/CHANGE 5 YEARS
OIL COOLERS	CHANGE EVERY 2 YEARS
VALVES	.RESET YEARLY
INJECTORS	.INSPECT AND POP-TEST EVERY 1000 HOURS
	.CHECK OIL FOR FUEL DILUTION (IF DILUTED CHANGE MORE FREQUENTLY)
	INSPECT FOR WHEAP HOLE FOR SEAL LEAKAGE EVERY 6 MONTHS
THERMOSTAT	REPLACE EVERY 2 YEARS, REPLACE GASKET
COOLING SYSTEM	FLUSH SYSTEM YEARLY (IF IN TROPICAL CLIMATE USE DISTILLED WATER, WATER CONDITIONER AND WATER PUMP LUBE.
FAN BELTS	
MOTOR MOUNTS	.INSPECT MOUNTS YEARLY
ENGINE ALIGNMENT	CHECK YEARLY
AIR CLEANER	.REPLACE ELEMENT YEARLY
OIL LINE/ FUEL LINES	.INSPECT FOR LEAKAGE OR BREAKAGE YEARLY
SEA STRAINER	
INSPECT ANTI-SYPHEN VALVE/KEEP CLEAN OR REPLACE CHECK AND REPLACE ZINCS EVERY 6 MOS.	

LEHMAN 80 & 120 HP - CHANGE THE INJECTION PUMP OIL EVERY 100 TO 150 HOURS